

## Experiment No-1:-Frequency reuse

### PART A

(PART A: TO BE REFERRED BY STUDENTS)

#### A.1 Aim

To understand the cellular network frequency reuse concept fulfilling the following objectives:

1. Finding the co-channel cells for a particular cell.
2. Finding the cell clusters within certain geographic area.

**A.2. Objectives:** To understand basics of cellular system

**A.3. Outcomes:** Students will able to carry out simulation of frequency reuse, hidden/exposed terminal.(LO-3)

#### A.4 Theory:

- In mobile communication systems a slot of a carrier frequency / code in a carrier frequency is a **radio resource unit**.
- This radio resource unit is assigned to a user in order to support a call/ session. **The number of available such radio resources at a base station thus determines the number of users who can be supported in the call.**
- Since in wireless channels a signal is "broadcast" i.e. received by all entities therefore one a resource is allocated to a user's it cannot be re-assigned until the user finished the call/ session. **Thus the number of users who can be supported in a wireless system is highly limited.**
- In order to support a large no. of users within a limited spectrum in a region the concept of frequency re-use is used.
- **The signal radiated from the transmitter antenna gets attenuated** with increasing distance. At a certain distance the signal strength falls below noise threshold and **is no longer identifiable.**

- In this region when the signal attenuates below noise floor the same radio resource may be used by another transmission to send different information.
- In term of cellular systems, the same radio resource (frequency) **can use by two base stations which are sufficiently spaced apart**. In this way **the same frequency gets reused** in a layer- geographic area **by two or more different base stations** different users simultaneously.
- Now what is important is to select the set of **base stations** which will use the same set of radio resources/ channel of frequencies or **technically the co-channel cells**.
- In this context the minimum adjacent set cells which use different frequencies each is called a cluster.
- The cellular concept is the major solution of the problem of spectral congestion and user capacity. Cellular radiorely on an intelligent allocation and channel reuse throughout a large geographical coverage region.

#### + **Cellular Frequency Reuse:**

- Each cellular base station is allocated a **group of radio channels** to be used within a small geographic area called a cell.
- Base stations in adjacent cells are assigned channel groups which contain completely different channels than neighbouring cells.
- Base station antennas are designed to achieve the desired coverage within a particular cell.  
**By limiting the coverage area within the boundaries of a cell, the same group of channels may be used to cover different cells that are separated from one another by geographic distances large enough to keep interference levels within tolerable limits.**

- The design process of selecting and allocating channel groups for all cellular base stations within a system is called frequency reuse or frequency planning.

#### + **Hexagonal Cell Structure:**

In figure 1, cells labelled with the same letter use the same group of channels. The hexagonal cell shape is conceptual and is the simplistic model of the radio coverage for each base station. It has been universally adopted since the hexagon permits easy and manageable analysis of a cellular system. The actual radio coverage of a system is known as the footprint and is determined from old measurements and propagation prediction models. Although the real footprint is amorphous in nature, a regular cell shape is needed for systematic system design and adaptation for future growth.

If a circle is chosen to represent the coverage area of a base station, adjacent circles overlaid upon a map leave gaps or overlapping regions. A square, an equilateral triangle and a hexagon can cover the entire area without overlap and with equal area. A cell must serve the weakest mobiles typically located at the edge of the cell within the foot print. For a given distance between the center of a polygon and its farthest perimeter points, the hexagon has the largest area of the three. Thus, with hexagon, the fewest number of cells can cover a geographic region and close approximation of a circular radiation pattern that occurs for an omni directional base antenna and free space propagation is possible.

Base station transmitters are situated either at the center of the cell (center-excited cells) or at three of the six cell vertices (edge-excited cells). Normally, omni directional antennas are used in center-excited cells and sectored directional antennas are used in edge-excited cells. Practical system design considerations permit a base station to be positioned up to onefourth the cell radius away from the ideal location.


#### + **Cell Cluster:**

Considering a cellular system that has a total of  $S$  duplex radio channels. If each cell is allocated a group of  $k$  channels ( $k < S$ ) and if the  $S$  channels are divided among  $N$  cells into unique and disjoint channel groups of same number of channels, then,

$$S = kN. \quad 6.1$$

The  $N$  cells that collectively use the complete set of available frequencies is called a cluster. If a cluster is replicated  $M$  times within the system, the total number of duplex channels or capacity,

$$C = MkN = MS. \quad 6.2$$



Frequency reuse concept, Cells with the same letter use the same set of frequencies. A cell cluster is outlined in blue color and replicated over the coverage area.

**In this example,**

The cluster size  $N = 7$  and the frequency reuse factor is  $1/7$  since **each cell contains one seventh of the total number of available channels.**

The capacity is directly proportional to M. The *factor N is called the cluster size and is typically 4, 7 or 12*. If the cluster size N is reduced while the cell size is kept constant, more clusters are required to cover a given area and hence more capacity is achieved from the


design viewpoint, the smallest possible value of N is desirable to maximize capacity over a

given coverage area. The frequency reuse factor of a cellular system is  $1/N$ , since each cell within a cluster is assigned  $1/N$  of the total available channels in the system.

#### Co-channel Cells:

A larger cluster size causes the ratio between the cell radius and the distance between cochannel cells to decrease reducing co-channel interference. The value of N is a function of how much interference a mobile or base station can tolerate while maintaining a sufficient quality of communications. *Since each hexagonal cell has six equidistant neighbors and the line joining the centers of any cell and each of its neighbors are separated by multiples of 60 degrees*, only certain cluster sizes and cell layouts are possible. To connect without gaps between adjacent cells, the geometry of hexagons is such that the number of cells per cluster, N, can only have values that satisfy,

$$N = i^2 + ij + j^2, \quad 6.3$$



Method of locating co-channel cells in a cellular system. In this figure, N=19(i.e., i =3, j=2).

**In this example, N = 19 (i.e., i = 3, j = 2).**

Where, i and j are non-negative integers.

To find the nearest co-channel neighbours of a particular cell,

a. move i cells along any chain of hexagons then,

b. turn 60 degrees counter-clockwise and move j cells.

## A.6 Steps

Follow the instructions given below to perform the experiments.

### ➤ Steps to perform Virtual lab Experiment:

**Virtual Lab: Fading Channel and Mobile Communication**


**Virtual Lab Link: <http://vlabs.iitkgp.ac.in/fcmc/index.html#>**

**Experiment: Frequency Reuse (Co-channel cells and Cell Cluster)**

**Starting the Experiments:-**


**LINK:** <http://vlabs.iitkgp.ernet.in/fcmc/exp6/index.html#>

- Step 1: Click on the experiment you want to do by clicking on either 'Click here to start Experiment 6A (Co-channel cell)' or 'Click here to start Experiment 6B (Cell cluster)'



### Performing Experiment 1A:- •

- Step 2: Let Experiment 6A (Co-channel cell) is chosen. Click on the button START. A page appears with a dialogue box asking for your name. Enter your name and click OK.




- Step 3: Choose the value of Cell Radius, i andj.

- Step 4: Click on the button Show Cells. For the given parameters, the value of Clustersize N is shown in the LHS of the page and the generated cells are shown on the RHS of the page.



- Step 5: Within the generated cells the center cell is shown in pink colour. Select the Co-channel cells in orange colour for the center cell by finding the Co-channel cells from the formula given in the theory section.




Step 6: Click on the button CHECK to see whether your manually selected Co-channel cells match with the correct Co-channel cells. If you're manually selected cells do not match with the correct Co-channel cells then the correct Co-channel cells are displayed in sky blue colour. If your manually selected Co-channel cells match with the correct Co-channel cells then the correct Co-channel cells are over-marked in green colour.



- Step 7: Click on the button REPORT to generate the report of the experiment you have performed.



- Step 8: A dialogue box appears. Click on the button Save to save your report.
- Step 9: A dialogue box appears with the message that 'Your report has generated successfully'. Click on button OK in the dialogue box




- Step 10: Now you can view the pdf report.

- Step 11: You can repeat the experiment by clicking the CLEAR button at the upper corner in the LHS of the page.


## Performing Experiment 1B:

- Step 12: Let Experiment 6B (Cell cluster) is chosen. Click on the button START. A page appears with a dialogue box asking for your name. Enter your name and click OK.




- Step 13: Choose the value of Cell Radius and Cell Cluster.

Step 14: Click on the button Show Cells. The generated cells are shown on the RHS of the page.



- Step 15: Within the generated cells the two extreme cells within the cell cluster is shown in pink colour. Select other cells within the cell cluster in orange colour.




- Step 16: Click on the button CHECK to see whether your manually selected cluster cells match with the correct cells of the cluster. If your manually selected cells do not match with the correct cells of the cluster then the correct cells of the cluster are displayed in

sky blue colour. If the manually selected cells of the cluster match with the correct cells of the cluster then the correct cells of the cluster are over-marked in green colour.




- Step 17: Click on the button REPORT to generate the report of the experiment you have performed.



- Step 18: A dialogue box appears. Click on the button Save to save your report.

- Step 19: A dialogue box appears with the message that 'Your report has generated successfully'. Click on button OK in the dialogue box.



- Step 20: Now you can view the pdf report.
- Step 21: You can repeat the experiment by clicking the CLEAR button at the upper corner in LHS of the page.

## PART B

### (PART B: TO BE COMPLETED BY STUDENTS)

*(Students must submit the soft copy as per following segments within two hours of the practical. The soft copy must be uploaded on the Blackboard or emailed to the concerned lab in charge faculties at the end of the practical in case there is no Black board access available)*

Roll. No. B30	Name: Pranjal Bhatt
Class :TE-B COMPS	Batch: B2
Date of Experiment:	Date of Submission:
Grade:	

### B. Software Code written by student:

#### C -Channel Python Code:

```
from math import cos, sin, radians, sqrt
from tkinter import *

class Hexagon:

    def __init__(self, parent, x, y, length, color, tags):
        self.parent = parent
        self.x = x
        self.y = y
        self.length = length
        self.color = color
        self.tags = tags
```

```
self.draw_hex()

def draw_hex(self):
    """Draw a hexagon based on center (x, y) and edge length"""
    coords = []
    for i in range(6):
        angle_rad = radians(60 * i)
        end_x = self.x + self.length * cos(angle_rad)
        end_y = self.y + self.length * sin(angle_rad)
        coords.append((end_x, end_y))
    self.parent.create_polygon(*sum(coords, ()), fill=self.color, outline="black", tags=self.tags)

def get_center(self):
    """Return the center coordinates of the hexagon"""
    return self.x, self.y

class FrequencyReuse(Tk):
    def __init__(self, i, j, columns=16, rows=10, edge_len=30):
        super().__init__()
        self.i = i
        self.j = j
        self.N = i**2 + i*j + j**2 # Correct cluster size calculation
        self.columns = columns
```

```
self.rows = rows

self.edge_len = edge_len

self.hexagons = {}

self.first_click = True

self.selected_hex = None

self.co_channel_cells = []

self.canvas = Canvas(self, width=800, height=650, bg="#Add0e1")

self.canvas.pack()

self.title(f"Frequency Reuse: Cluster Size {self.N}")

self.create_grid()

self.create_textbox()

self.canvas.bind("<Button-1>", self.call_back)

self.canvas.bind("<Shift-R>", self.reset_grid)

self.mainloop()

def create_grid(self):

    """Create a grid of hexagons"""

    size = self.edge_len

    for c in range(self.columns):

        offset = 0 if c % 2 == 0 else size * sqrt(3) / 2

        for r in range(self.rows):

            x = c * (size * 1.5) + 50

            y = (r * (size * sqrt(3))) + offset + 15
```

```
tag = f"{{r}},{{c}}"

self.hexagons[tag] = Hexagon(self.canvas, x, y, self.edge_len, "#fafafa", tag)

def create_textbox(self):
    """Create the instruction text box"""

    self.textbox = Label(self.canvas, text="Select a Hexagon", font=("Helvetica", 12), bg="white", width=80)
    self.canvas.create_window(400, 600, window=self.textbox)

def write_text(self, text):
    """Update text in instruction box"""

    self.textbox.config(text=text)

def reset_grid(self, event=None):
    """Reset the grid and selection"""

    self.first_click = True

    self.selected_hex = None

    self.co_channel_cells = []

    self.canvas.delete("lines") # Clear previous lines

    for hexagon in self.hexagons.values():

        self.canvas.itemconfigure(hexagon.tags, fill="#fafafa")

        self.write_text("Select a Hexagon")

def find_co_channel_cells(self, start_tag):
```

"""Find co-channel cells based on (i, j) movement"""

```
r_start, c_start = map(int, start_tag.split(","))  
  
co_cells = [(r_start, c_start)] # Include original cell
```

```
# Directions to move in the hexagonal grid
```

```
directions = [
```

```
    (self.i, self.j),  
  
    (-self.i, -self.j),  
  
    (self.j, -self.i-self.j),  
  
    (-self.j, self.i+self.j),  
  
    (self.i+self.j, -self.j),  
  
    (-self.i-self.j, self.j)
```

```
]
```

```
for dr, dc in directions:
```

```
    r_new, c_new = r_start + dr, c_start + dc
```

```
    tag_new = f"{{r_new}},{{c_new}}"
```

```
    if tag_new in self.hexagons:
```

```
        co_cells.append((r_new, c_new))
```

```
return co_cells
```

```
def draw_line(self, tag):
```

```
"""Draw a line from the selected hexagon to the correctly guessed co-channel cell"""

if not self.selected_hex:
    return

start_x, start_y = self.hexagons[self.selected_hex].get_center()
end_x, end_y = self.hexagons[tag].get_center()
self.canvas.create_line(start_x, start_y, end_x, end_y, fill="blue", width=2, tags="lines")

def call_back(self, evt):
    """Handle user clicks on hexagons"""

    selected_hex_id = self.canvas.find_closest(evt.x, evt.y)[0]
    selected_tag = self.canvas.gettags(selected_hex_id)[0]

    if self.first_click:
        # First selection
        self.first_click = False
        self.selected_hex = selected_tag
        self.co_channel_cells = self.find_co_channel_cells(selected_tag)

        # Highlight first selection
        self.canvas.itemconfigure(selected_tag, fill="green")
        self.write_text(f"Selected cell {selected_tag}. Now, select co-channel cells.")
```

```
else:  
  
    # Subsequent selections  
  
    r, c = map(int, selected_tag.split(","))  
  
    if (r, c) in self.co_channel_cells and selected_tag != self.selected_hex:  
  
        self.canvas.itemconfigure(selected_tag, fill="green")  
  
        self.draw_line(selected_tag) # Draw line for correct selections  
  
        self.write_text(f"Correct! Cell {selected_tag} is a co-channel cell.")  
  
    else:  
  
        self.canvas.itemconfigure(selected_tag, fill="red")  
  
        self.write_text(f"Incorrect! Cell {selected_tag} is not a co-channel cell.")  
  
  
if len(self.co_channel_cells) >= 7: # 1 Original + 6 Co-Cells  
  
    self.write_text("Great! Press Shift-R to restart.")  
  
  
if __name__ == '__main__':  
  
    print("Enter i & j values. Common (i, j) values are: (1,0), (1,1), (2,0), (2,1), (3,0), (2,2)")  
  
    i = int(input("Enter i: "))  
  
    j = int(input("Enter j: "))  
  
    if i == 0 and j == 0:  
  
        raise ValueError("i & j both cannot be zero")  
  
    elif j > i:  
  
        raise ValueError("Value of j cannot be greater than i")  
  
    else:
```

```
print(f"Cluster size (N) = {i**2 + i*j + j**2}")
```

```
FrequencyReuse(i, j)
```

### Cell Clustering code in Python:

```
import tkinter as tk

from tkinter import ttk

import matplotlib.pyplot as plt

import numpy as np

from matplotlib.backends.backend_tkagg import FigureCanvasTkAgg
```

```
def hexagon(x, y, size):
    """Generate hexagon coordinates."""
    angles = np.linspace(0, 2 * np.pi, 7)
    return x + size * np.cos(angles), y + size * np.sin(angles)
```

```
def plot_clusters(cluster_size):
    """Plot the frequency reuse cell clusters with green and yellow colors."""
    fig, ax = plt.subplots(figsize=(6, 6))
    size = 10
    colors = ["green", "yellow"] # Only 2 colors for clusters

    cell_count = 1 # Start cell numbering
```

```
for i in range(-cluster_size, cluster_size + 1):
    for j in range(-cluster_size, cluster_size + 1):
        x = i * 1.5 * size
        y = j * np.sqrt(3) * size + (i % 2) * (np.sqrt(3) / 2 * size)
        cluster_id = (i + j) % 2 # Alternating clusters
        color = colors[cluster_id]

        # Draw hexagon
        ax.fill(*hexagon(x, y, size), color=color, edgecolor='black')

        # Display cell number at center of hexagon
        text_color = "white" if color == "green" else "black"
        ax.text(x, y, str(cell_count), ha='center', va='center', fontsize=10, color=text_color, fontweight='bold')

        cell_count += 1 # Increment cell count

    ax.set_xlim(-cluster_size * 15, cluster_size * 15)
    ax.set_ylim(-cluster_size * 15, cluster_size * 15)
    ax.set_aspect('equal')
    ax.axis("off")
return fig

def update_plot():
```

```
"""Update the plot based on user input."""

try:

    cluster_size = int(cluster_size_var.get())

    if cluster_size < 1:

        error_label.config(text="Please enter a positive integer")

        return

    for widget in plot_frame.winfo_children():

        widget.destroy()

    fig = plot_clusters(cluster_size)

    new_canvas = FigureCanvasTkAgg(fig, master=plot_frame)

    new_canvas.get_tk_widget().pack()

    new_canvas.draw()

    error_label.config(text="")

except ValueError:

    error_label.config(text="Please enter a valid number")

# GUI Setup

root = tk.Tk()

root.title("Cell Clustering - Frequency Reuse")
```

```
frame = ttk.Frame(root, padding=10)
frame.pack()

# Cluster Size Input
cluster_size_var = tk.StringVar(value="3")
ttk.Label(frame, text="Cluster Size:").grid(row=0, column=0)
ttk.Entry(frame, textvariable=cluster_size_var, width=5).grid(row=0, column=1)
ttk.Button(frame, text="Update", command=update_plot).grid(row=0, column=2)


error_label = ttk.Label(frame, text="", foreground="red")
error_label.grid(row=1, column=0, columnspan=3)

# Plot Frame
plot_frame = ttk.Frame(root)
plot_frame.pack()

# Initial Plot
fig = plot_clusters(int(cluster_size_var.get()))
canvas = FigureCanvasTkAgg(fig, master=plot_frame)
canvas.get_tk_widget().pack()
canvas.draw()
root.mainloop()
```

## B.2 Input and Output:

### Co-channel Allocation:



The screenshot shows a Python code editor and a graphical interface side-by-side.

**Code Editor (Left):**

```

EX1 (1).py
C:\Users\HP\Downloads> python EX1 (1).py
1  from math import cos, sin, radians, sqrt
2  from tkinter import *
3
4  class Hexagon:
5      def __init__(self, parent, x, y, length, color, tags):
6          self.parent = parent
7          self.x = x
8          self.y = y
9          self.length = length
10         self.color = color
11         self.tags = tags
12         self.draw_hex()
13
14     def draw_hex(self):
15         """Draw a hexagon based on center (x, y) and edge length"""
16         coords = []
17         for i in range(6):
18             angle_rad = radians(60 * i)
19             end_x = self.x + self.length * cos(angle_rad)
20             end_y = self.y + self.length * sin(angle_rad)
21             coords.append((end_x, end_y))
22         self.parent.create_polygon(*sum(coords, ()), fill=self.color, outline="")
23
24     def get_center(self):
25         """Return the center coordinates of the hexagon"""
26         return self.x, self.y
27
28 class FrequencyReuse(Tk):
29     def __init__(self, i, j, columns=16, rows=10, edge_len=30):
30         super().__init__()
31         self.i = i
32         self.j = j
33         self.N = i**2 + i*j + j**2 # Correct cluster size calculation
34         self.columns = columns
35         self.rows = rows
36         self.edge_len = edge_len
37         self.hexagons = {}


```

**Graphical Interface (Right):**

A hexagonal grid visualization titled "Frequency Reuse: Cluster Size 7". The grid consists of white and red hexagons. A central cluster of hexagons is colored red, while the surrounding hexagons are white. Three green hexagons are placed at the centers of three hexagons in the red cluster. Blue lines connect the centers of these three green hexagons, forming a triangle. A message at the bottom right says "Great! Press Shift-R to restart."



## Cell Cluster:



## B.3 Observations and learning:

The experiment demonstrates that frequency reuse is an essential concept for efficient spectrum utilization in cellular networks. By allocating the same frequency to co-channel cells separated by sufficient distance, interference is minimized while maximizing user capacity. The hexagonal cell structure ensures optimal coverage without overlaps or gaps, making it ideal for network design. Smaller cluster sizes increase capacity but require careful interference management. Overall, frequency reuse enables scalable, high-capacity cellular systems, forming the foundation of modern communication technologies like GSM, LTE, and 5G.

#### B.4 Conclusion:

Frequency reuse is a key concept in cellular networks that allows efficient spectrum utilization, increased capacity, and reduced interference. By strategically assigning frequencies to non-adjacent cells, networks can serve more users while maintaining good signal quality.

#### B.5 Question of Curiosity

1. With Example explain Co-channel cells

Co-channel cells are cells in a cellular network that use the same frequency but are separated by a certain distance to avoid interference. Since frequencies are reused in a cellular system, co-channel cells are carefully placed so that interference is minimized.

Example:

Consider a cellular network with a cluster size ( $N = 7$ ). This means the available frequencies are divided among 7 cells before being reused.

If we label the cells as A, B, C, D, E, F, and G, then:

- Cell A will use the same frequency as other Cell A's in the network, which are spaced apart.
- These distant cells using the same frequency are called co-channel cells.

##### Visual Representation (Hexagonal Grid Example):

mathematica

Copy Edit

A	B	C	D	E	F	G
B	C	D	E	F	G	A
C	D	E	F	G	A	B
D	E	F	G	A	B	C

In this layout, all "A" cells are co-channel cells because they share the same frequency but are separated by a distance to reduce interference.

2. Define following Term:

a) Cell

A cell is a small geographical area in a cellular network covered by a single base station.

- It is typically hexagonal in shape.
- Each cell has a unique set of frequencies, except for co-channel cells, which reuse the same frequency.
- Cells collectively form a large network.

b) Frequency Reuse

Frequency reuse is a technique in cellular communication where the same frequency is used in different, non-adjacent cells to increase spectrum efficiency.

- A group of cells (called a cluster) use different frequencies.
- These frequencies are then reused in another cluster at a safe distance.

■ Example:

If a network has  $N = 7$ , it means:

- The frequencies are split across 7 different cells.
- These frequencies are reused in another cluster, ensuring minimal interference.

c) Cell Splitting

Cell splitting is a method of increasing network capacity by dividing large cells into smaller cells.

- It is done in high-traffic areas to handle more users.
- Smaller cells have lower power base stations and use the same frequency more efficiently.

■ Example:

A large macro cell can be split into multiple microcells or pico cells to serve more users in dense urban areas.

